



## LZR<sup>®</sup>-FLATSCAN S

COMPACT LASER SENSOR FOR INDUSTRIAL  
DOORS, GATES, AND BARRIERS

MAX. DETECTION RANGE: 18' × 18'

**User's Guide** for product version 0101 and higher.  
See product label for serial number.




Visit website for  
available languages  
of this document.

## DESCRIPTION


Flatscan S is a compact, single-curtain, laser sensor with an opening angle of 90°. The sensor provides high-resolution coverage with 400 spots and configurable object size detection according to the given application.

The laser sensor is CLASS 1 certified device according to IEC 60825-1. The visible laser beams are CLASS 2, and will automatically time out during normal operation.



1. Protective cover (to be removed after mounting)
2. Housing
3. Laser window
4. LED signal
5. USB connector (factory use only)
6. Visible laser beams
7. Internal calibration interface (DO NOT OPEN)
8. Screw hole

### SOLD SEPARATELY - REQUIRED FOR INSTALLATION



LZR-FLATSCAN S Mounting Bracket  
(10FSSMB)



Universal Remote Control  
(10REMOTE)

# TECHNICAL SPECIFICATIONS

## TECHNOLOGY / PERFORMANCE

<b>Technology</b>	LASER sensor, time-of-flight measurement
<b>Detection mode</b>	presence
<b>Max. detection range</b>	max. 18' × 18' (13 1/8' @ 5% reflectivity)
<b>Opening angle</b>	90°
<b>Tilt angles</b>	±3° (with bracket)
<b>Emission characteristics</b>	wavelength 905nm; max. output pulse power 25W (CLASS 1) wavelength 635nm; max. output CW power 0.95mW (CLASS 2) visible spot
<b>Angular resolution</b>	0.23° (400 spots within 90°)
<b>LEDs</b>	1 tri-colored LED: detection / output status

## ELECTRICAL

<b>Supply voltage</b>	12 – 24 VDC ±15%
<b>Power consumption</b>	≤ 2.3W, peak current: 1A
<b>Response time</b>	max. 50ms (+ output activation delay)
<b>Output</b>	1 opto (galvanic isolation - polarity free)
max. switching voltage	42 VAC/VDC
max. switching current	100mA
	1 relay (free of potential contact)
max. contact voltage	42 VAC/VDC
max. contact current	1A (resistive)
max. switching power	30W DC / 60 VAC

## PHYSICAL

<b>Dimensions</b>	5" (L) × 3 1/2" (H) × 2" (D) (without bracket)
<b>Color</b>	black
<b>Protection degree</b>	IP66 (IEC 60529)
<b>Temperature range (when powered)</b>	-22 – 140 °F (-30 – 60 °C)
<b>Humidity</b>	0 – 95% non-condensing
<b>Vibrations</b>	< 2G





## COMPLIANCE

<b>Compliance</b>	IEC 60825-1, IEC 60950-1, IEC 61000-6-2, IEC 61000-6-3, IEC 60529:2001
-------------------	--





*Specifications are subject to change without prior notice.  
All values measured in specific conditions.*

# LED SIGNALS


## COLOR

-  detection
-  power on
-  error LED
-  no power


## BEHAVIOR

-  LED flashes
-  LED flashes quickly
-  LED flashes slowly
-  LED is off


## INSTALLATION AND MAINTENANCE NOTES



Avoid extreme vibrations.



Do not cover the laser window.




Avoid moving objects and light sources in the detection field.



Avoid the presence of smoke and fog in the detection field.



Avoid condensation.




Avoid exposure to sudden and extreme temperature changes.



Avoid direct exposure to high pressure cleaning.



Do not use dry or dirty towels or aggressive products to clean the laser window.




Keep the sensor permanently powered in environments where the temperature can drop below 14°F.



Do not look into the laser emitter or the visible red laser beams.



The warranty is invalid if unauthorized repairs are made or attempted by unauthorized personnel.



Clean the laser window with compressed air.

When needed, wipe the laser window only with a soft, clean, damp microfiber cloth.



Only trained and qualified personnel are recommended to install and set up the sensor.

## SAFETY TIPS



The device contains IR and visible laser beams.

IR laser: wavelength 905nm; max. output pulse power 25W (Class 1 according to IEC 60825-1)

Visible laser: wavelength 635nm; max. output CW power 0.95mW (Class 2 according to IEC 60825-1)

The visible laser beams can be deactivated during normal operation. The installer can activate the visible beams if needed.



### CAUTION!

Use of controls, adjustments, or performance of procedures other than those specified herein may result in hazardous radiation exposure.

Ensure compliance with applicable local, national, and international codes and standards.

## SYMBOLS



Caution!  
Laser radiation



Attention



Factory values



Note





Remote control  
sequence



Possible  
remote control  
adjustments

## NOTES ON VISIBLE LASER BEAMS

- Visible laser beams are used for the estimation of curtain coverage during the initial adjustment stage. For precise installation of the sensor, please evaluate your detection field and adjust curtain accordingly (see Detection Field, page 13).
- The shape of the laser spot is oval. The farther the laser spot emits, the more the spot diffuses. Refer to diagram below to calculate the position.
- A visible spot has around  $\pm 1/2$ " deviation at 10' distance. Please ensure that the curtain is in the correct position.



Distance (ft)	b (in)	a (in)
3.28	0.49	0.06
6.56	0.98	0.12
9.84	1.48	0.18
13.12	1.97	0.24
16.40	2.46	0.30

# 1 MOUNTING


*A mounting bracket is required for FLATSCAN S installation.*

*The instructions in this User's Guide describe the use of FLATSCAN S Mounting Bracket.*

- Use the sensor mounting screws to secure the sensor to the bracket in the correct position (i.e. laser window at 90°).
- Use the Mounting Bracket mounting screws to secure bracket (with sensor) to the desired mounting location. Note: BEA recommends a mounting height of 14 – 17" for vehicle detection in a horizontal mounting orientation.
- If necessary, adjust the angle of the sensor by loosening and tightening the tilt angle screw of the FLATSCAN S Mounting Bracket. Fine-tuning the angle will be done later.
- Remove the red, protective cover from the laser window and ensure that nothing is obstructing the window.



# 2 WIRING



If monitoring is not connected, the cable must be wired to the power cable.



Ensure that the sensor is properly grounded (connected to the earth).

1. If only VAC power is available, a 12V transformer paired with a rectifier must be used. Do not use a 24V transformer and rectifier as this will cause damage to the product.

2. Output status when sensor is operational (can be NO or NC). See page 15, OUTPUT CONFIGURATION.

### 3 FIELD POSITIONING

This section illustrates the field positioning in 3 possible applications (doors, barrier arms, and sliding gates) and the respective field orientations (vertical or horizontal) for each.

Follow the instructions for your given application.

#### DOORS: Vertical Field


1. Activate visible laser beams.




**Do not look directly into the visible beams!**

This same key sequence will turn OFF the visible laser beams.

2. Select mounting side - left or right.



LEFT MOUNT



RIGHT MOUNT


3. If necessary, position the field using the tilt angle screw. Loosen the screw to move the field closer to the door and tighten the screw to move the field away from the door.

**NOTE:** See page 5 for more information on the visible laser beams.

LOOSEN = FIELD IN



TIGHTEN = FIELD OUT



### 3 FIELD POSITIONING

#### BARRIER ARMS: Horizontal Field


1. Activate visible laser beams.




**⚠ Do not look directly into the visible beams!**

*This same key sequence will turn OFF the visible laser beams.*

2. Select mounting side - left or right.



LEFT MOUNT



RIGHT MOUNT




3. If necessary, position the field using the tilt angle screw. Loosen the screw to angle the field down and tighten the screw to angle the field up.

**NOTE:** See page 5 for more information on the visible laser beams.



LOOSEN = FIELD DOWN



TIGHTEN = FIELD UP



*When the approaching area is sloped, be sure that the sensor tilt angle closely matches the slope angle to ensure that the intended target can be detected at the specified distance.*





### 3 FIELD POSITIONING

#### SLIDING GATES: Horizontal Field


1. Activate visible laser beams.




**⚠ Do not look directly into the visible beams!**

*This same key sequence will turn OFF the visible laser beams.*

2. Select mounting side - left or right.



LEFT MOUNT




RIGHT MOUNT


3. If necessary, position the field using the tilt angle screw. Loosen the screw to angle the field down and tighten the screw to angle the field up.

**NOTE:** See page 5 for more information on the visible laser beams.



LOOSEN = FIELD DOWN



TIGHTEN = FIELD UP



*When the approaching area is sloped, be sure that the sensor tilt angle closely matches the slope angle to ensure that the intended target can be detected at the specified distance.*



### 3 FIELD POSITIONING

#### SLIDING GATES: Vertical Field


1. Activate visible laser beams.




**⚠ Do not look directly into the visible beams!**

*This same key sequence will turn OFF the visible laser beams.*

2. Select mounting side - left or right.



LEFT MOUNT



RIGHT MOUNT


3. If necessary, position the field using the tilt angle screw. Loosen the screw to move the field closer to the door and tighten the screw to move the field away from the gate.

**NOTE:** See page 5 for more information on the visible laser beams.

LOOSEN = FIELD IN



TIGHTEN = FIELD OUT




## 4 TEACH-IN

Use the following remote control key sequence to learn the detection area.

**IMPORTANT:** Be sure to clear the detection field before the teach-in process begins.

**NOTE:** If the Detection Field size is changed from the default, you must perform the appropriate teach-in for the given field.



## REMOTE CONTROL SETTINGS (OPTIONAL)

### DETECTION FIELD


Customize the detection field by increasing/decreasing distances on both sides for both fields.

**AE** = FIELD 1, width


**BE** = FIELD 1, depth

**CE** = FIELD 2, width

**DE** = FIELD 2, depth



left mount



right mount

The FLATSCAN S sensor is configured to understand metric measurements.

If necessary, please convert your measurements from imperial to metric by multiplying your imperial measurements by 0.3.

FIELD 1	<b>AE</b>	0 0 0	-	5 5 0	550 cm
	width	0 cm		550 cm	550 cm
	<b>BE</b>	0 0 0	-	5 5 0	550 cm
	depth	0 cm		550 cm	550 cm
FIELD 2*	<b>CE</b>	0 0 0	-	5 5 0	550 cm
	width	0 cm		550 cm	550 cm
	<b>DE</b>	0 0 0	-	5 5 0	550 cm
	depth	0 cm		550 cm	550 cm

\* Please note that the detection range can be guaranteed with 5% reflectivity at 13' diagonal when fog filter value is set to 0, if the fog filter value is not 0, then the guaranteed detection distance will be shortened with 5% reflectivity.

## REMOTE CONTROL SETTINGS (OPTIONAL)


### IMMUNITY FILTER

Increasing the immunity filter decreases false detections caused by environment interference such as rain and snow.



### UNCOVERED ZONE

Uncovered zone shortens the detection field size (e.g. to avoid leaves or snow on the ground or to avoid an adjacent wall).




Measured in specific conditions and determined by application and installation.

### FOG FILTER

Fog filter helps increase sensor performance in areas with fog. As you increase filter, you decrease interference from fog.

e.g. Environments with dense fog should choose higher settings.




Note 1: The sensor will automatically launch teach-in with every adjustment. Ensure that the detection field is clear before the teach-in process begins.

Note 2: Measurements are max detection distances with a 5% reflective object.

### MINIMUM OBJECT SIZE


Rejects object smaller than the specified object size.



Based on full field size, not the current field size.

### OUTPUT ACTIVATION DELAY

Output triggered when detection lasts longer than the specified time.



### DETECTION AREA ACTIVATION

Turns on/off detection fields 1 or 2.



## REMOTE CONTROL SETTINGS (OPTIONAL)

### DETECTION FIELD REDIRECTION

Redirects outputs of detection fields 1 or 2.

	F1	0	1	2	3
OUTPUT 1	field 1	field 1	field 2	field 1 or field 2	error alarm*
OUTPUT 2	field 2	field 2	field 1	error alarm*	field 1 or field 2

\* errors associated with the LED behavior identified in TROUBLESHOOTING

### OUTPUT CONFIGURATION (when powered)

	1	2	3	4	
OUTPUT 1	NO	NC	NC	NO	POWERED (no detection)
					POWERED (detection)
					NOT POWERED
OUTPUT 2*	NC	NO	NC	NO	POWERED (no detection)
					POWERED (detection)
					NOT POWERED

\* OUTPUT 2 default connection: pink/gray

NO = normally open  
NC = normally closed

### ANTIMASKING & BACKGROUND

**Antimasking:** when laser window is covered, the sensor will go into error mode.

**Background:** sensor movement can cause a compromised background, sending the sensor into error mode

	2	3
antimasking	ON	ON
background*	OFF	ON

\* Do not set background to ON when sensor is mounted in a horizontal orientation. If done, this will cause the sensor to go into error mode.

### LED ACTIVATION

	0	1
LED	LED off	LED on



**IMPORTANT:** Ensure compliance with applicable local, national, and international codes and standards.

# HOW TO USE THE REMOTE CONTROL

The remote control is most effective within 13 feet of the sensor.



After unlocking, the red LED flashes and the sensor can be adjusted by remote control.



If the red LED flashes quickly after unlocking, you need to enter an access code from 1 to 4 digits. If you do not know the access code, **cycle the power**. During 1 minute, you can access the sensor without introducing any access code.



To end an adjustment session, always lock the sensor.

## ADJUSTING ONE OR MORE PARAMETERS



## CHECKING A VALUE



x = number of flashes = value of the parameter



## RESTORING TO FACTORY VALUES



## SAVING AN ACCESS CODE

The access code is recommended for sensors installed close to each other and can be established to prevent unauthorized operation



## DELETING AN ACCESS CODE




\* Please complete this setting within 1 minute after power on.

## RESTORING TO DEFAULTS





**Full:** resets all parameters to factory settings

**Partial:** resets all parameters except detection field, output configuration, and output redirection to factory settings



If unused for 30 minutes, the sensor will time out of the remote control session. Cut and restore power supply. The remote control session is accessible again within 30 minutes.

# TROUBLESHOOTING

	The ORANGE LED is on permanently.	The sensor has encountered a memory problem.	Contact BEA Technical Services.
	The ORANGE LED flashes 1x / 2x / 3x every 3 seconds.	The sensor signals an internal fault. <i>If the internal error still exists after 3 resets, the LED will flash 9 times and the sensor will be locked.</i>	Cut and restore power supply. If orange LED flashes again, send the sensor back to manufacturer.
	The ORANGE LED flashes 4x every 3 seconds.	Error for antimasking or boundary.	Check if there's pollution on front window and clean the window if necessary. Check sensor orientation and that background setting is appropriate for the given orientation.
	The ORANGE LED flashes 5x every 3 seconds.	Error occurred during the teach-in process.	Relaunch a teach-in.

## BEA, INC. INSTALLATION/SERVICE COMPLIANCE EXPECTATIONS

### FOR ALL APPLICATIONS:

The installation is provided by CUSTOMER or its affiliates. BEA is not affiliated with CUSTOMER or any of its affiliates. BEA has no liability to CUSTOMER or the end user for any and all liability, claims, demands, obligations, actions, losses, costs, damages, fees or expenses (including attorneys' fees and legal costs) arising out of or in connection with product installation, or the end user's use of or inability to use the product, the installation services, product defects or malfunctions, including, but not limited to, any actual or alleged injury, damage, death or other consequence occurring to any person or property as a result, directly or indirectly, of installation, possession, or use of any product or services provided by CUSTOMER or any individual or entity acting for or on behalf of CUSTOMER, whether claimed by reason of breach of warranty, negligence, product defect or otherwise, and regardless of the form in which any such claim is made (collectively, the "Released Matters"). You, on behalf of yourself and each of the Releasor Parties, hereby releases and absolutely and irrevocably discharges each Hippo Party and their respective officers, directors, employees, representatives and agents from and against any Released Matters. You acknowledge and agree that the foregoing is a full and final release of all Released Matters, including those that are unknown, unanticipated or unsuspected or that may hereafter arise as a result of the discovery of new and/or additional facts, and you expressly waive all rights under Section 1542 of the Civil Code of California as well as any similar statutes of any other jurisdictions, which you acknowledge you have read and understood and which provides as follows: A GENERAL RELEASE DOES NOT EXTEND TO CLAIMS WHICH THE CREDITOR DOES NOT KNOW OR SUSPECT TO EXIST IN HIS FAVOR AT THE TIME OF EXECUTING THE RELEASE, WHICH IF KNOWN BY HIM MUST HAVE MATERIALLY AFFECTED HIS SETTLEMENT WITH THE DEBTOR.

### FOR DOOR, GATE, OR BARRIER APPLICATIONS:

BEA, Inc., the sensor manufacturer, cannot be held responsible for incorrect installations or incorrect adjustments of the sensor/device; therefore, BEA, Inc. does not guarantee any use of the sensor/device outside of its intended purpose.

BEA, Inc. strongly recommends that installation and service technicians be AAADM-certified for pedestrian doors, IDA-certified for doors/gates, and factory-trained for the type of door/gate system.

Installers and service personnel are responsible for executing a risk assessment following each installation/service performed, ensuring that the sensor/device system performance is compliant with local, national, and international regulations, codes, and standards.

Once installation or service work is complete, a safety inspection of the door/gate shall be performed per the door/gate manufacturer's recommendations and/or per AAADM/ANSI/DASMA guidelines (where applicable) for best industry practices. Safety inspections must be performed during each service call – examples of these safety inspections can be found on an AAADM safety information label (e.g. ANSI/DASMA 102, ANSI/DASMA 107, UL294, UL325, and International Building Code).

Verify that all appropriate industry signage, warning labels, and placards are in place.



Tech Support: 1-800-407-4545 | Customer Service: 1-800-523-2462  
General Tech Questions: techservices-us@BEAsensors.com | www.BEAsensors.com

A Halma company

©BEA | Original Instructions | PLEASE KEEP FOR FURTHER USE - DESIGNED FOR COLOR PRINTING