



## IS40

	RC-symbol	Parameter n°	Factory value	Available values
SENSITIVITY		x1	x7	0-9
REJECTION MODE		x2	x1	1-5
DETECTION MODE		x3	x2	1-3
MAX. DURATION OF PRESENCE DETECTION		x4	x8	0-9
TARGET SIZE		x5	x1	1-7
IMMUNITY FILTER IR-FIELD		x6	x2	1-3
FREQUENCY		x7	x1	1-2
IR PATTERN SIZE		x8	x1	1-9
MOTION CONFIGURATION		x9		0-3 NOT USED
OUTPUT		x10		0-6
OUTPUT CONFIGURATION		x11	x1	1-4 NOT USED
MOTION HOLDDTIME		x12		0-9 NOT USED

## IS40P

	RC-symbol	Parameter n°	Factory value	Available values
MAX. DURATION OF PRESENCE DETECTION		x1	x8	0-9
TARGET SIZE		x2	x1	1-7
IMMUNITY FILTER IR-FIELD		x3	x2	1-3
FREQUENCY		x4	x1	1-2
IR PATTERN SIZE		x5	x1	1-9
MOTION CONFIGURATION		x6		0-3 NOT USED
OUTPUT CONFIGURATION		x7	x1	1-4 NOT USED
MOTION HOLDDTIME		x8		0-9 NOT USED

## FALCON

	RC-symbol	Parameter n°	Factory value	Available values
FIELD SIZE		x1	x7	0-9
HOLD TIME		x2		0-9
OUTPUT CONFIGURATION		x3	x1	1-2
DETECTION MODE		x4	x2	1-3
DETECTION FILTER		x5	x1	1-6