

3) CONNECT IN SERIES WITH DOOR POSITION SWITCH WHEN USED WITH BR3-X RESTROOM CONTROL MODULE

- 4) ONE POWER SUPPLY CAN BE USED TO POWER ALL DEVICES.
- 5) KIT DOES NOT INCLUDE POWER SUPPLY, PUSH PLATES, ELECTRIC STRIKE OR DOOR CONTROL

Upon completion of the installation or service work, at a minimum, perform a daily safety check in accordance with the minimum inspection guidelines provided by AAADM. Provide each equipment owner with an owner's manual that includes a daily safety checklist and contains, at a minimum, the information recommended by AAADM. Offer an information session with the equipment owner explaining how to perform daily inspections and point out the location of power/operation switches to disable the equipment if a compliance issue is noted. The equipment should be inspected annually in accordance with the minimum inspection guidelines. A safety check that includes, at a minimum, the items listed on the safety information label must be performed during each service call. If you are not an AAADM certified inspector, BEA strongly recommends you have an AAADM certified inspector perform an AAADM inspection and place a valid inspection sticker below the safety information label prior to putting the equipment into operation.

24/7 Tech Support: 1-800-407-4545 | Customer Service: 1-800-523-2462 | General Tech Questions: Tech_Services@beainc.com | Tech Docs: www.beasensors.com



100 ENTERPRISE DRIVE PITTSBURGH, PA 15275 PHONE: (412) 249-4100 FAX: (412) 249-4101 EMAIL: www.beasensors.com

TITLE: Br3-X RESTROOM KIT/ EMERGENCY ADD ON KIT (NORMALLY LOCKED & UNLOCKED)

SIZE:	DRAWN BY: WJR	REV BY:	PART NO: 80.0397.00
A	SCALE:	DATE:	SHEET
	NONE	14 MARCH 2017	1 OF 1

EMERGENCY SIGNAGE (70.5675)

