



- NOTES: 1) JUMPERS JP1,JP2 ARE PLACED ON PINS 1,2 AND 4,5 FOR DRY CONTACTS ON RELAY OUTPUT #2.
 2) PUSH PLATE, MOTION SENSOR, CARD READER MUST BE DRY CONTACT.
 3) TRANSFORMER AND BRIDGE RECTIFIER VOLT/ AMPERE RATING IS DETERMINED BY CURRENT DRAW OF ELECTRIC STRIKE.
 4) BRIDGE RECTIFIER SUPPLIED BY OTHERS.

IF AFTER TROUBLESHOOTING A PROBLEM, A SATISFACTORY SOLUTION CANNOT BE ACHIEVED, PLEASE CALL B.E.A., INC. FOR FURTHER ASSISTANCE DURING EASTERN STANDARD TIME AT 1-800-523-2462 FROM 8AM - 5PM. FOR AFTER-HOURS, CALL EAST COAST: 1-866-836-1863 OR 1-800-407-4545 / MID-WEST: 1-888-308-8843 / WEST COAST: 1-888-419-2564. DO NOT LEAVE ANY PROBLEM UNRESOLVED. IF YOU MUST WAIT FOR THE FOLLOWING WORKDAY TO CALL B.E.A., LEAVE THE DOOR INOPERABLE UNTIL SATISFACTORY REPAIRS CAN BE MADE. NEVER SACRIFICE THE SAFE OPERATION OF THE AUTOMATIC DOOR OR GATE FOR AN INCOMPLETE SOLUTION.WEB: WWW.BEASENSORS.COM

BEA
 We open up New Horizons
 A HALMA GROUP COMPANY
 100 ENTERPRISE DRIVE
 PITTSBURGH, PA 15275
 PHONE: (412) 249-4100
 FAX: (412) 249-4101
 EMAIL: www.beasensors.com

**TITLE: MC-25 WITH ELECTRIC STRIKE,
 APT. BUZZER RELAY/ FIRE ALARM**

SIZE: A	DRAWN BY: KJG	REV BY: KJG	PART NO: 80.0019.02
	SCALE: NONE	DATE: 18 MAY 2005	SHEET 1 OF 1