



NOTES: 1) BEA RECOMMENDS USING THE LO-21 AND SAFETY BEAM.
 2) LO21 RED AND BLACK CONNECTIONS SHOWN FOR RH OPERATOR. REVERSE ON LH OPERATOR.
 3) THE HOLD ADJUSTMENT MAY NEED TO BE INCREASED (> +12 VDC) FOR PROPER OPERATION.
 4) WHEN USING DC VOLTAGE YOU MUST RESPECT POLARITY ORANGE: (-) BROWN: (+)
 5) WHEN USING THE LO-21S SWINGSIDE SUPERSkans MUST BE INSTALLED TO COMPLY WITH ANSI 156.10-2005

IF AFTER TROUBLESHOOTING A PROBLEM, A SATISFACTORY SOLUTION CANNOT BE ACHIEVED, PLEASE CALL B.E.A., INC. FOR FURTHER ASSISTANCE DURING EASTERN STANDARD TIME AT 1-800-523-2462 FROM 8AM - 5PM. FOR AFTER-HOURS, CALL EAST COAST: 1-866-836-1863 OR 1-800-407-4545 / MID-WEST: 1-888-308-8843 / WEST COAST: 1-888-419-2564. DO NOT LEAVE ANY PROBLEM UNRESOLVED. IF YOU MUST WAIT FOR THE FOLLOWING WORKDAY TO CALL B.E.A., LEAVE THE DOOR INOPERABLE UNTIL SATISFACTORY REPAIRS CAN BE MADE. NEVER SACRIFICE THE SAFE OPERATION OF THE AUTOMATIC DOOR OR GATE FOR AN INCOMPLETE SOLUTION.WEB: WWW.BEASENSORS.COM

		100 ENTERPRISE DRIVE PITTSBURGH, PA 15275 PHONE: (412) 249-4100 FAX: (412) 249-4101 EMAIL: www.beasensors.com	
TITLE: BESAM 300/400 CONTROL with LO-21, LO21S, BODYGUARD/ DK-12, AND OLD STYLE DK-12			
SIZE: B	DRAWN BY: KJG	REV BY: TUC	PART NO: 80.0065.03
SCALE: NONE	DATE: 22 AUG 2006	SHEET: 1 OF 1	