

NOTES: 1) LO21U DIPSWITCH SETTINGS #1-5 (LOCK-OUT TIME), #6 (DOWN/ON), #7 (UP/ OFF), #8 (DOWN/ ON). 2) SHOWN LH,RH MAGIC SWING AND RH MAGIC FORCE FOR LH MAGIC FORCE REVERSE LO21B/U RED AND

3) IF NO BREAK OUT IS USED A JUMPER MUST BE INSTALLED BETWEEN TERMINALS 6 AND 8.

IF AFTER TROUBLESHOOTING A PROBLEM, A SATISFACTORY SOLUTION CANNOT BE ACHIEVED, PLEASE CALL B.E.A., INC. FOR FURTHER ASSISTANCE DURING EASTERN STANDARD TIME AT 1-800-523-2462 FROM 8AM - 5PM. FOR AFTER-HOURS, CALL EAST COAST: 1-866-836-1863 OR 1-800-407-4545 / MID-WEST: 1-888-308-8843 / WEST COAST: 1-888-419-2564. DO NOT LEAVE ANY PROBLEM UNRESOLVED. IF YOU MUST WAIT FOR THE FOLLOWING WORKDAY TO CALL B.E.A., LEAVE THE DOOR INOPERABLE UNTIL SATISFACTORY REPAIRS CAN BE MADE. NEVER SACRIFICE THE SAFE OPERATION OF THE AUTOMATIC DOOR OR GATE FOR AN INCOMPLETE SOLUTION.WEB: WWW.BEASENSORS.COM



100 ENTERPRISE DRIVE PITTSBURGH, PA 15275 PHONE: (412) 249-4100 FAX: (412) 249-4101

EMAIL: www.beasensors.com

TITLE: STANLEY MP CONTROL WITH LO21B/U

	SIZE:	DRAWN BY: KJG	REV BY: WJR	PART NO: 80.0127.04
	Α	SCALE:	DATE:	SHEET
		NONE	02 DEC. 2010	1 OF 1

