


- NOTES: 1) SW-1 SETTINGS (UP IS OFF) 1.PUSH-N-GO 2. LATCH ASSIST 3. RATCHET FUNCTION 4. STACK PRESSURE.
 2) DUAL CONTROL SHOWN
 3) SW-1 CALIBRATION SWITCH REMOVE JUMPER AFTER 1ST ACTIVATION AFTER INITIAL POWER UP. STORE ON 1 POST.

IF AFTER TROUBLESHOOTING A PROBLEM, A SATISFACTORY SOLUTION CANNOT BE ACHIEVED, PLEASE CALL B.E.A., INC. FOR FURTHER ASSISTANCE DURING EASTERN STANDARD TIME AT 1-800-523-2462 FROM 8AM - 5PM. FOR AFTER-HOURS, CALL EAST COAST: 1-866-836-1863 OR 1-800-407-4545 / MID-WEST: 1-888-308-8843 / WEST COAST: 1-888-419-2564. DO NOT LEAVE ANY PROBLEM UNRESOLVED. IF YOU MUST WAIT FOR THE FOLLOWING WORKDAY TO CALL B.E.A., LEAVE THE DOOR INOPERABLE UNTIL SATISFACTORY REPAIRS CAN BE MADE. NEVER SACRIFICE THE SAFE OPERATION OF THE AUTOMATIC DOOR OR GATE FOR AN INCOMPLETE SOLUTION.WEB: WWW.BEASENSORS.COM

		100 ENTERPRISE DRIVE PITTSBURGH, PA 15275 PHONE: (412) 249-4100 FAX: (412) 249-4101 EMAIL: www.beasensors.com	
TITLE: KM 3000/3100 (MICRO) K-CONTROL LO21K, W/PARALLAX 2 SYSTEM Q-DISCONNECT ON APPROACH SIDE			
SIZE: B	DRAWN BY: KJG	REV BY: TUC	PART NO: 80.0176.02
SCALE: NONE	DATE: 01 DEC 2005	SHEET 1 OF 1	