


- NOTE: 1) BODYGUARD SHALL BE 40" APART CENTER TO CENTER
 2) SWITCH SHALL OPEN 10 DEGREES OR LESS FROM CLOSE POSITION.
 3) THE BODYGUARD RELAY OUTPUT FUNCTION MUST BE CHANGED TO A VALUE OF 2. THE DEFAULT VALUE IS 1.

IF AFTER TROUBLESHOOTING A PROBLEM, A SATISFACTORY SOLUTION CANNOT BE ACHIEVED, PLEASE CALL B.E.A., INC. FOR FURTHER ASSISTANCE DURING EASTERN STANDARD TIME AT 1-800-523-2462 FROM 8AM - 5PM. FOR AFTER-HOURS, CALL EAST COAST: 1-866-836-1863 OR 1-800-407-4545 / MID-WEST: 1-888-308-8843 / WEST COAST: 1-888-419-2564. DO NOT LEAVE ANY PROBLEM UNRESOLVED. IF YOU MUST WAIT FOR THE FOLLOWING WORKDAY TO CALL B.E.A., LEAVE THE DOOR INOPERABLE UNTIL SATISFACTORY REPAIRS CAN BE MADE. NEVER SACRIFICE THE SAFE OPERATION OF THE AUTOMATIC DOOR OR GATE FOR AN INCOMPLETE SOLUTION. WEB: WWW.BEASENSORS.COM

 100 ENTERPRISE DRIVE PITTSBURGH, PA 15275 PHONE: (412) 249-4100 FAX: (412) 249-4101 EMAIL: www.beasensors.com			
TITLE: DOUBLE EGRESS W/LO21P, BODYGUARD, EAGLE, PUSH PLATE KNOWING ACT			
SIZE:	DRAWN BY:	REV BY:	PART NO:
A	TUC	TUC	80.0204.01
	SCALE:	DATE:	SHEET
	NONE	11 NOV 2005	1 OF 1