



- NOTES: 1) OPTIONAL AUX. SWITCH SHOULD OPEN AT APPROX. 65-70 DEGREES. SET CONTROL FUNCTION DIAL TO 6. IF NOT USED, BEA RECOMMENDS CONTROL FUNCTION DIAL SET TO 5.
 2) RH MOTOR SHOWN, REVERSE MOTOR SWITCH ON PARALLINK FOR LH MOTOR.
 3) BODYGUARD MUST BE PROGRAMMED TO RELAY VALUE 2. DEFAULT IS 1.
 4) IF DOROMATIC INTERFACE CABLE & CHIP IS PREVIOUSLY INSTALLED. IT MUST BE REMOVED.

IF AFTER TROUBLESHOOTING A PROBLEM, A SATISFACTORY SOLUTION CANNOT BE ACHIEVED, PLEASE CALL B.E.A., INC. FOR FURTHER ASSISTANCE DURING EASTERN STANDARD TIME AT 1-800-523-2462 FROM 8AM - 5PM. FOR AFTER-HOURS, CALL EAST COAST: 1-866-836-1863 OR 1-800-407-4545 / MID-WEST: 1-888-308-8843 / WEST COAST: 1-888-419-2564. DO NOT LEAVE ANY PROBLEM UNRESOLVED. IF YOU MUST WAIT FOR THE FOLLOWING WORKDAY TO CALL B.E.A., LEAVE THE DOOR INOPERABLE UNTIL SATISFACTORY REPAIRS CAN BE MADE. NEVER SACRIFICE THE SAFE OPERATION OF THE AUTOMATIC DOOR OR GATE FOR AN INCOMPLETE SOLUTION. WEB: WWW.BEASENSORS.COM



100 ENTERPRISE DRIVE
 PITTSBURGH, PA 15275
 PHONE: (412) 249-4100
 FAX: (412) 249-4101
 EMAIL: www.beasensors.com

**TITLE: PARALLINK, DOROMATIC
 ASTRO SWING CONTROL**

SIZE: A	DRAWN BY: KJG	REV BY: TUC	PART NO: 80.0220.01
	SCALE: NONE	DATE: 12SEP2005	SHEET 1 OF 1