



NOTE:

- 1) WIRE LO-21 RED / BLACK WIRES TO SWITCH WHEN STACK OR LATCH ASSIST FUNCTIONS ARE TURNED ON.
- 2) AN ADDITIONAL MICROSWITCH WILL NEED INSTALLED ON OPERATOR ORIENTED 180 DEGREES FROM CLOSED LATCH SPEED SWITCH.
- 3) SW-1 SETTINGS (UP IS OFF) 1.PUSH-N-GO 2. LATCH ASSIST 3. RATCHET FUNCTION 4. STACK PRESSURE.
- 4) DUAL CONTROL SHOWN
- 5) SW-1 CALIBRATION SWITCH REMOVE JUMPER AFTER 1ST ACTIVATION AFTER INITIAL POWER UP. STORE ON 1 POST.
- 6) IF MICROCELLS ARE USED IN LIEU OF SBK BEAMS THEN WIRE THE MICROCELL OUTPUT COM. & N.O. TO THE LO21K PURPLE & GREY RESPECTIVELY. DO NOT USE THE BLACK/WHITE WIRE.
- 7) MAY REQUIRE SECONDARY RE-ACTIVATION SENSOR DEPENDING ON LOCATION OF KNOWING ACT DEVICE.

IF AFTER TROUBLESHOOTING A PROBLEM, A SATISFACTORY SOLUTION CANNOT BE ACHIEVED, PLEASE CALL B.E.A., INC. FOR FURTHER ASSISTANCE DURING EASTERN STANDARD TIME AT 1-800-523-2462 FROM 8AM - 5PM. FOR AFTER-HOURS, CALL EAST COAST: 1-866-836-1863 OR 1-800-407-4545 / MID-WEST: 1-888-308-8843 / WEST COAST: 1-888-419-2564. DO NOT LEAVE ANY PROBLEM UNRESOLVED. IF YOU MUST WAIT FOR THE FOLLOWING WORKDAY TO CALL B.E.A., LEAVE THE DOOR INOPERABLE UNTIL SATISFACTORY REPAIRS CAN BE MADE. NEVER SACRIFICE THE SAFE OPERATION OF THE AUTOMATIC DOOR OR GATE FOR AN INCOMPLETE SOLUTION.WEB: WWW.BEASENSORS.COM



100 ENTERPRISE DRIVE
 PITTSBURGH, PA 15275
 PHONE: (412) 249-4100
 FAX: (412) 249-4101
 EMAIL: www.beasensors.com

**TITLE: KM 3000/3100 (MICRO) K-CONTROL
 LO21K, BODYGUARD,EAGLE,PUSH
 PLATE,MC25,EL STRIKE**

SIZE: A	DRAWN BY: KJG	REV BY: EOF	PART NO: 80.0229.01
	SCALE: NONE	DATE: 29 SEPT, 2005	SHEET 1 OF 1