



DPS = Door position switch

- NOTES 1) DOOR POSITION SWITCHES ARE NORMALLY CLOSED SWITCH IS CLOSED WHEN DOOR IS CLOSED.
- 2) FOR 3 OR 4 DOOR INTERLOCK ELIMINATE DPS 5, DPS 6, SECOND RELAY AND THIRD BR-3.
- 3) IF IT IS A 3 OR 5 DOOR INTERLOCK INPUT 4 ON EACH BR-3 MUST STILL BE CONNECTED TO THE REPECTIVE RELAY TO WORK PROPERLY.

IF AFTER TROUBLESHOOTING A PROBLEM, A SATISFACTORY SOLUTION CANNOT BE ACHIEVED, PLEASE CALL B.E.A., INC. FOR FURTHER ASSISTANCE DURING EASTERN STANDARD TIME AT 1-800-523-2462 FROM 8AM - 5PM. FOR AFTER-HOURS, CALL EAST COAST: 1-866-836-1863 OR 1-800-407-4545 / MID-WEST: 1-888-308-8843 / WEST COAST: 1-888-419-2564. DO NOT LEAVE ANY PROBLEM UNRESOLVED. IF YOU MUST WAIT FOR THE FOLLOWING WORKDAY TO CALL B.E.A., LEAVE THE DOOR INOPERABLE UNTIL SATISFACTORY REPAIRS CAN BE MADE. NEVER SACRIFICE THE SAFE OPERATION OF THE AUTOMATIC DOOR OR GATE FOR AN INCOMPLETE SOLUTION.WEB: WWW.BEASENSORS.COM

100 ENTERPRISE DRIVE  
PITTSBURGH, PA 15275  
PHONE: (412) 249-4100  
FAX: (412) 249-4101  
EMAIL: www.beasensors.com

**TITLE: BR-3 WITH 3, 4, 5 or 6 DOOR INTERLOCK**

SIZE:	DRAWN BY:	REV BY:	PART NO:
A	WJR		80.0330.01
	SCALE:	DATE:	SHEET
	NONE	15 APRIL 2010	1 OF 1