



**NOTES:**

- 1) IF INSTALLING ON A MANUAL DOOR DISREGARD RELAY 2 CONNECTIONS AND DOOR CONTROL.  
IF INSTALLING ON AN AUTOMATIC DOOR ENSURE THE DOOR HAS THE APPROPRIATE SENSORS INSTALLED AND THAT IT COMPLIES TO ANSI 156.10 OR 156.19.

IF AFTER TROUBLESHOOTING A PROBLEM, A SATISFACTORY SOLUTION CANNOT BE ACHIEVED, PLEASE CALL B.E.A., INC. FOR FURTHER ASSISTANCE DURING EASTERN STANDARD TIME AT 1-800-523-2462 FROM 8AM - 5PM. FOR AFTER-HOURS, CALL EAST COAST: 1-866-836-1863 OR 1-800-407-4545 / MID-WEST: 1-888-308-8843 / WEST COAST: 1-888-419-2564. DO NOT LEAVE ANY PROBLEM UNRESOLVED. IF YOU MUST WAIT FOR THE FOLLOWING WORKDAY TO CALL B.E.A., LEAVE THE DOOR INOPERABLE UNTIL SATISFACTORY REPAIRS CAN BE MADE. NEVER SACRIFICE THE SAFE OPERATION OF THE AUTOMATIC DOOR OR GATE FOR AN INCOMPLETE SOLUTION. WEB: WWW.BEASENSORS.COM

100 ENTERPRISE DRIVE PITTSBURGH, PA 15275 PHONE: (412) 249-4100 FAX: (412) 249-4101 EMAIL: www.beasensors.com			
<b>TITLE: BR3-RD433-MAGLOCK/EL STRIKE POWERED W/ ALTRONIX POWER SUPPLY</b>			
SIZE: <b>A</b>	DRAWN BY: WJR	REV BY:	PART NO: <b>80.0332.01</b>
SCALE: NONE	DATE: 07/27/2010	SHEET 1 OF 1	

