



- NOTES: 1) WHEN REQUIRED, SET "B" SWITCH TO NORMALLY OPEN. MUST CLOSE CONTACT AT APPROX. 65-70 DEGREES.
 2) INSTALL A JUMPER WIRE ON PINS 17, 18 OF THE CONTROL
 3) RH MOTOR SHOWN, REVERSE LO-21 RED AND BLACK WIRES FOR LH MOTOR.
 4) HOLD ADJUSTMENT MAY NEED TO BE ADJUSTED TO 12 VOLTS OR ABOVE FOR PROPER OPERATION OF LOCKOUT.

IF AFTER TROUBLESHOOTING A PROBLEM, A SATISFACTORY SOLUTION CANNOT BE ACHIEVED, PLEASE CALL B.E.A., INC. FOR FURTHER ASSISTANCE DURING EASTERN STANDARD TIME AT 1-800-523-2462 FROM 8AM - 5PM. FOR AFTER-HOURS, CALL EAST COAST: 1-866-836-1863 OR 1-800-407-4545 / MID-WEST: 1-888-308-8843 / WEST COAST: 1-888-419-2564. DO NOT LEAVE ANY PROBLEM UNRESOLVED. IF YOU MUST WAIT FOR THE FOLLOWING WORKDAY TO CALL B.E.A., LEAVE THE DOOR INOPERABLE UNTIL SATISFACTORY REPAIRS CAN BE MADE. NEVER SACRIFICE THE SAFE OPERATION OF THE AUTOMATIC DOOR OR GATE FOR AN INCOMPLETE SOLUTION. WEB: WWW.BEASENSORS.COM



100 ENTERPRISE DRIVE
 PITTSBURGH, PA 15275
 PHONE: (412) 249-4100
 FAX: (412) 249-4101
 EMAIL: www.beasensors.com

TITLE: BESAM 300/400 (ETIK2) WITH LO-21, PARALLAX 2 SYSTEM

SIZE: A	DRAWN BY: KJG	REV BY: KJG	PART NO: 80.0056.04
	SCALE: NONE	DATE: 20 MAR 2006	SHEET 1 OF 1