



- NOTES: 1) BEA RECOMMENDS USING THE LO-21 WITH SAFETY BEAMS OR A SWING SIDE SUPER SCAN TO ENSURE COMPLIANCE WITH ANSI 156.10.
 2) LO21 RED AND BLACK WIRES MUST BE CONNECTED TO MASTER OPERATOR MOTOR
 3) SET FUNCTION CONTROL TO "CARPET" FOR PROPER OPERATION
 4) WHEN USING DC VOLTAGE, POLARITY MUST BE RESPECTED: ORANGE (-), BROWN (+)

IF AFTER TROUBLESHOOTING A PROBLEM, A SATISFACTORY SOLUTION CANNOT BE ACHIEVED, PLEASE CALL B.E.A., INC. FOR FURTHER ASSISTANCE DURING EASTERN STANDARD TIME AT 1-800-523-2462 FROM 8AM - 5PM. FOR AFTER-HOURS, CALL EAST COAST: 1-866-836-1863 OR 1-800-407-4545 / MID-WEST: 1-888-308-8843 / WEST COAST: 1-888-419-2564. DO NOT LEAVE ANY PROBLEM UNRESOLVED. IF YOU MUST WAIT FOR THE FOLLOWING WORKDAY TO CALL B.E.A., LEAVE THE DOOR INOPERABLE UNTIL SATISFACTORY REPAIRS CAN BE MADE. NEVER SACRIFICE THE SAFE OPERATION OF THE AUTOMATIC DOOR OR GATE FOR AN INCOMPLETE SOLUTION. WEB: WWW.BEASENSORS.COM

		100 ENTERPRISE DRIVE PITTSBURGH, PA 15275 PHONE: (412) 249-4100 FAX: (412) 249-4101 EMAIL: www.beasensors.com	
TITLE: DOM ASTRO-SWING CONTROL with LO-21, LO21S, BODYGUARD/ DK-12			
SIZE: B	DRAWN BY: KJG	REV BY: JDC	PART NO: 80.0081.02
SCALE: NONE	DATE: 20 MARCH 2006	SHEET: 1 OF 1	