



NOTES: 1) IF USING AN ACTIVATION DEVICE WITH A WET OUTPUT CONNECT IT TO THE WET INPUT OF THE Br-3.
 CARD READER MAY BE EXCHANGED FOR A PUSH PLATE.
 2) IF USING A DC STRIKE YOU WILL NEED TO INSERT A RECTIFIER AT THE STRIKE.

EXAMPLE PROGRAMMING:

THIS EXAMPLE WILL PROVIDE A 5 SECOND ACTIVATION SIGNAL TO EACH DOOR CONTROL AND A 5 SECOND ACTIVATION DELAY BETWEEN EACH DOOR CONTROL.

BEGIN BY PROGRAMMING BOTH Br-3s TO FUNCTION 35 THEN SET THE SUB FUNCTIONS AS FOLLOWS:

Br-3 A: h1=2, h2=5, h3=5, d1=_2, d2=5

Br-3 B: h1=5, h2=2, h3=5, d1=4, d2=5

IF AFTER TROUBLESHOOTING A PROBLEM, A SATISFACTORY SOLUTION CANNOT BE ACHIEVED, PLEASE CALL B.E.A., INC. FOR FURTHER ASSISTANCE DURING EASTERN STANDARD TIME AT 1-800-523-2462 FROM 8AM - 5PM. FOR AFTER-HOURS, CALL EAST COAST: 1-866-836-1863 OR 1-800-407-4545 / MID-WEST: 1-888-308-8843 / WEST COAST: 1-888-419-2564. DO NOT LEAVE ANY PROBLEM UNRESOLVED. IF YOU MUST WAIT FOR THE FOLLOWING WORKDAY TO CALL B.E.A., LEAVE THE DOOR INOPERABLE UNTIL SATISFACTORY REPAIRS CAN BE MADE. NEVER SACRIFICE THE SAFE OPERATION OF THE AUTOMATIC DOOR OR GATE FOR AN INCOMPLETE SOLUTION. WEB: WWW.BEASENSORS.COM

100 ENTERPRISE DRIVE
 PITTSBURGH, PA 15275
 PHONE: (412) 249-4100
 FAX: (412) 249-4101
 EMAIL: www.beasensors.com

**TITLE: BR-3 TWO DOOR
 BIDIRECTIONAL SEQUENCEING WITH
 ELECTRIC LOCK. FUNCTION 35**

SIZE: A	DRAWN BY: WJR	REV BY:	PART NO: 80.0312.00
	SCALE: NONE	DATE: 07 JAN. 2010	SHEET 1 OF 1

