



NOTES:

- 1) ENSURE THAT THE POWER SUPPLY IS CAPABLE OF PROVIDING ENOUGH CURRENT TO POWER THE RD433, ISO RELAY AND STIKE AT THE SAME TIME.
- 2) ON THE RD433, SET THE LEFT DIP SWITCH TO "PUL" AND THE RIGHT DIP SWITCH TO "10". THIS WILL GIVE YOU A 10 SECOND HOLD TIME ON THE ELECTRIC STRIKE.

IF AFTER TROUBLESHOOTING A PROBLEM, A SATISFACTORY SOLUTION CANNOT BE ACHIEVED, PLEASE CALL B.E.A., INC. FOR FURTHER ASSISTANCE DURING EASTERN STANDARD TIME AT 1-800-523-2462 FROM 8AM - 5PM. FOR AFTER-HOURS, CALL EAST COAST: 1-866-836-1863 OR 1-800-407-4545 / MID-WEST: 1-888-308-8843 / WEST COAST: 1-888-419-2564. DO NOT LEAVE ANY PROBLEM UNRESOLVED. IF YOU MUST WAIT FOR THE FOLLOWING WORKDAY TO CALL B.E.A., LEAVE THE DOOR INOPERABLE UNTIL SATISFACTORY REPAIRS CAN BE MADE. NEVER SACRIFICE THE SAFE OPERATION OF THE AUTOMATIC DOOR OR GATE FOR AN INCOMPLETE SOLUTION.WEB: WWW.BEASENSORS.COM

100 ENTERPRISE DRIVE
PITTSBURGH, PA 15275
PHONE: (412) 249-4100
FAX: (412) 249-4101
EMAIL: www.beasensors.com

TITLE:

**RD433 RECIEVER W/ POWER SUPPLY,
ISO RELAY AND ELECTRIC STRIKE.**

SIZE: A	DRAWN BY: WJR	REV BY:	PART NO: 80.0344.00
	SCALE: NONE	DATE: 23 Sept. 2011	SHEET 1 OF 1



