






INTERIOR IXIXO DT1

EXTERIOR IXIO DT1



SL500 CONTROL



20	(+) Lock delay
19	Lock
18	(+) Lock
17	(+) 24 V DC
16	Inner Impulse
15	(-) 0 V DC
14	(+) 24 V DC
13	Presence Test
12	Key Impulse
11	Presence Impulse 2
10	C-switch
9	Presence Impulse 1
8	(-) 0 V DC
7	(+) 24 V DC
6	Side Presence Test
5	Outer Impulse
4	Side Presence Impulse 2
3	Stop Impulse
2	Side Presence Impulse 1
1	(-) 0 V DC

NOTES: 1) CAN POWER SENSOR FROM CONTROL BOX

AFTER TROUBLESHOOTING A PROBLEM, A SATISFACTORY SOLUTION CANNOT BE ACHIEVED, FOR FURTHER ASSISTANCE PLEASE CALL B.E.A., INC. TECHNICAL SERVICE AT 1-800-523-2462. DO NOT LEAVE ANY PROBLEM UNRESOLVED. IF YOU MUST WAIT FOR THE FOLLOWING WORKDAY TO CALL B.E.A., LEAVE THE DOOR INOPERABLE UNTIL SATISFACTORY REPAIRS CAN BE MADE. NEVER SACRIFICE THE SAFE OPERATION OF THE AUTOMATIC DOOR OR GATE FOR AN INCOMPLETE SOLUTION. WEB: WWW.BEASENSORS.COM

 100 ENTERPRISE DRIVE PITTSBURGH, PA 15275 PHONE: (412) 249-4100 FAX: (412) 249-4101 EMAIL: www.beasensors.com			
TITLE: BESAM SL500 WITH IXIO-DT1			
SIZE:	DRAWN BY: WJR	REV BY: JED	PART NO: 80.0353.00
A	SCALE: NONE	DATE: 15 FEB., 2013	SHEET 1 OF 1

