

▽

BLUE /WHITE	TEST -	8
BLUE	TEST +	7
GREEN /WHITE	RELAY 2	6
WHITE /BLACK	RELAY 2	5
GREEN	RELAY 1	4
WHITE	RELAY 1	3
BLACK	POWER	2
RED	POWER	1

NOTES:

- 1) SET LZR i30 ACTIVE DETECTION FIELDS (DOUBLE ENDED ARROW) TO "1122" WHICH ASSIGNS CURTAINS C1 AND C2 TO RELAY 1 (OPTIONAL FIELD) AND CURTAINS C3 AND C4 TO RELAY 2 (SAFETY FIELD)
- 2) SET SAFETY FIELD DIMENSIONS (C AND D BUTTONS) TO SIZE LARGE ENOUGH TO COVER THE FIRST DOOR WHERE SENSOR IS MOUNTED. SET OPTIONAL FIELD DIMENSIONS (A AND B BUTTONS) TO SIZE LARGE ENOUGH TO COVER BOTH DOORS.
- 3) SET OUTPUT CONFIGURATION ON LZR i30 (RELAY SYMBOL) TO "4".
- 4) SET BR3 TO FUNCTION "65" PER USERS GUIDE. SET H1 = 01, H2 = 01 AND D1 = _1.

IF AFTER TROUBLESHOOTING A PROBLEM, A SATISFACTORY SOLUTION CANNOT BE ACHIEVED, PLEASE CALL B.E.A., INC. FOR FURTHER ASSISTANCE DURING EASTERN STANDARD TIME AT 1-800-523-2462 FROM 8AM - 5PM. FOR AFTER-HOURS, CALL EAST COAST: 1-866-836-1863 OR 1-800-407-4545 / MID-WEST: 1-888-308-8843 / WEST COAST: 1-888-419-2564. DO NOT LEAVE ANY PROBLEM UNRESOLVED. IF YOU MUST WAIT FOR THE FOLLOWING WORKDAY TO CALL B.E.A., LEAVE THE DOOR INOPERABLE UNTIL SATISFACTORY REPAIRS CAN BE MADE. NEVER SACRIFICE THE SAFE OPERATION OF THE AUTOMATIC DOOR OR GATE FOR AN INCOMPLETE SOLUTION.WEB: WWW.BEASENSORS.COM

BEA
OPEN UP NEW HORIZONS
HALMA GROUP COMPANY

100 ENTERPRISE DRIVE
 PITTSBURGH, PA 15275
 PHONE: (412) 249-4100
 FAX: (412) 249-4101
 EMAIL: www.beasensors.com

TITLE: Br3 AND LZR i30 TO ACTIVATE TWO DOORS INDEPENDENTLY

SIZE: A	DRAWN BY: WJR	REV BY:	PART NO: 80.0401.00
	SCALE: NONE	DATE: 05 APRIL, 2017	SHEET 1 OF 1

△