

# MAIN MENU

## QUICK START menu

**TEACH IN settings**  
 Pull Cord  
 Walk All  
 Background  
 Install

**PRESETTINGS settings**  
 ColdRoom  
 Corner  
 Corridor  
 Standard

**> More menu**  
 ServiceMode  
 TeachInDelay  
 FactoryReset  
 Heating

**Service Mode settings**  
 ON  
 OFF

**Teach In Delay settings**  
 120 s  
**60 s**  
 30 s

**Factory Reset settings**  
 Partial  
 Full

**Heating settings**  
 AUTO  
 ECO  
**OFF**

## IN-OUT menu

**Out1 Funct settings**  
 Mot Pull Pres  
 Mot Pull Safe  
 Mot+ & Height  
 Mot+ & Speed  
 Pull Cord  
**Safety**  
 Presence  
 Mot Pull  
 Motion  
 Not Used

**Out2 Funct settings**  
 Mot Pull Pres  
 Mot Pull Safe  
 Mot+ & Height  
 Pres & Height  
 Pull Cord  
**Safety**  
 Presence  
 Mot Pull  
 Motion  
 Not Used

**Relay Funct settings**  
 Mot Pull Pres  
 Mot Pull Safe  
 Mot+ & Height  
 Mot+ & Speed  
 Pull Cord  
**Safety**  
 Presence  
 Mot Pull  
**Motion**  
 Not Used

**> More menu**  
 Out1 Logic  
 Out1 Holdtime  
 Out1 Test  
 Out2 Logic  
 Out2 Holdtime  
 Out2 Test  
 Relay Logic  
 Relay Holdtime  
 Relay Test

**Out1 Logic settings**  
 NC **NO**

**Out1 Holdtime settings**  
 20 min 10 s  
 10 min 5 s  
 5 min 3 s  
 1 min **1 s**  
 30 s 100 ms

**Out1 Test settings**  
 ON **OFF**

**Out2 Logic settings**  
 NC **NO**

**Out2 Holdtime settings**  
 20 min 10 s  
 10 min 5 s  
 5 min 3 s  
 1 min **1 s**  
 30 s 100 ms

**Out2 Test settings**  
 ON **OFF**

**Relay Logic settings**  
 Active NO NC  
 Passiv NC NO

**Relay Holdtime settings**  
 20 min 10 s  
 10 min 5 s  
 5 min 3 s  
 1 min **1 s**  
 30 s 100 ms

**Relay Test settings**  
 ON **OFF**

## MOTION menu

**Field Width settings**  
 0 - 999 [240.1]

**Field Stop settings**  
 0 - 999 [287.4]

**Object Type settings**  
 Any  
 Vehicle  
 Vehicle Depth

**> More menu**  
 Immunity  
 Field Start  
 Direction

**Immunity settings**  
 1 4  
**2** 5  
 3

**Field Start OFF settings**  
 0 - 999 [0.0]

**Direction settings**  
 Uni  
 Uni 100%+  
 Uni rev  
**Uni 100%**  
 Any

## PRESENCE menu

**Field Width settings**  
 0 - 999 [240.1]

**Field Stop settings**  
 0 - 999 [78.7]

**Object Type settings**  
 Any  
 Vehicle  
 Vehicle Depth

**> More menu**  
 Immunity  
 Field Start  
 PresTime

**Immunity settings**  
 1 4  
**2** 5  
 3

**Field Start OFF settings**  
 0 - 999 [0.0]

**PresTime settings**  
 Infinite  
 120 min  
 60 min  
 30 min  
 10 min  
 5 min  
 2 min  
 1 min  
 30 s

## SAFETY menu

**Field Width settings**  
 0 - 999 [240.1]

**Field Stop settings**  
 0 - 999 [15.7]

**> More menu**  
 Immunity  
 PresTime  
 UncovZone

**Immunity settings**  
 1 4  
**2** 5  
 3

**PresTime settings**  
 Infinite  
 120 min  
 60 min  
 30 min  
 10 min  
 5 min  
 2 min  
 1 min  
 30 s

**UncovZone settings**  
 49.2 9.8"  
 39.4 **5.9"**  
 29.5 3.9"  
 19.7 2"  
 13.8

## OTHERS menu

**ObjectType+ settings**  
 Any  
 Vehicle  
 Vehicle Depth

**PullMinTime settings**  
 0 4 8  
 1 5 9  
 2 6  
**3** 7

**PullObjType settings**  
 Any  
 Vehicle  
 Vehicle Depth

**HeightMin settings**  
 157.5" 98.4"  
 137.3" **88.6"**  
 127.9" 78.7"  
 118.1" 68.9"  
 108.3"

**SpeedMax settings**  
 31 mph 15.5 mph  
 28 mph 12.4 mph  
 24.8 mph 9.3 mph  
 21.7 mph 6.2 mph  
 18.6 mph 3.1 mph

## > DIAGNOSTIC menu

**FieldDisplay**

**QR-code**

**ID #**

**Event Log**

**ResetLog**  
 Yes No

**Sensor Temp**

**Power Supply**

**Operating Time**

**RC password**

**Language**  
 English Deutsch French

**Display units**  
 Inch Meter

**> Specific menu**  
 In-Out menu MinObjHeight menu  
 Motion menu TiltAngle  
 Presence menu ForceTilt menu  
 Safety menu LateralAngle  
 IntegObjMode ForceLateral menu  
 Nb curtains menu MountHeight  
 DistFilter menu ForceHeight menu

**In-Out menu**  
 Input Logic

**Input Logic settings**  
 High **Low**

**Motion menu**  
 InvertField

**InvertField settings**  
 Yes **No**

**Presence menu**  
 InvertField

**InvertField settings**  
 Yes **No**

**Safety menu**  
 HoldOpenHght  
 InvertField

**HoldOpenHght settings**  
 49.2" 19.7  
 39.4 **13.8"**  
 29.5 9.8"

**InvertField settings**  
 Yes **No**

**IntegObjMode settings**  
 Standard Infinite

**Nb curtains settings**  
 7 5 3 1  
 6 4 2

**DistFilter settings**  
 Both **TimeBased**

**MinObjHeight settings**  
 49.2" 19.7" 5.9"  
 39.4" 13.8" 3.9"  
 29.5" 9.8" 2"

**ForceTilt/ForceLateral/ForceHeight settings**  
 Manual **Auto**

**> Admin menu**

Config PN

SoftPIN

# LZR®-WIDESCAN MENU TREE

Config: 42.4371.06  
 Software: V3.2

