

NOTES:

INSIDE PUSH PLATE WILL ALWAYS RELEASE LOCK AND ACTIVATE DOOR.
CARD READER WILL SIGNAL ACCESS CONTROL PANEL WHICH WILL RELEASE LOCK AND ENABLE OUTSIDE PUSH PLATE.
ACCESS CONTROL TIMER WILL DETERMINE HOW LONG LOCK WILL BE RELEASED AND OUTSIDE PUSH PLATE IS ENABLED.

100 ENTERPRISE DRIVE
PITTSBURGH, PA 15275
PHONE: (412) 249-4100
FAX: (412) 249-4101
EMAIL: www.beasensors.com

TITLE: BR-3 WITH ELECTRIC STRIKE, PUSH PLATES, CARD READER, DAY, NIGHT MODE

SIZE:	DRAWN BY:	REV BY:	PART NO:
A	WJR		80.0346.00
	SCALE: NONE	DATE: 27 MARCH 2012	SHEET 1 OF 1

IF AFTER TROUBLESHOOTING A PROBLEM, A SATISFACTORY SOLUTION CANNOT BE ACHIEVED, PLEASE CALL B.E.A., INC. FOR FURTHER ASSISTANCE DURING EASTERN STANDARD TIME AT 1-800-523-2462 FROM 8AM - 5PM. FOR AFTER-HOURS, CALL EAST COAST: 1-866-836-1863 OR 1-800-407-4545 / MID-WEST: 1-888-308-8843 / WEST COAST: 1-888-419-2564. DO NOT LEAVE ANY PROBLEM UNRESOLVED. IF YOU MUST WAIT FOR THE FOLLOWING WORKDAY TO CALL B.E.A., LEAVE THE DOOR INOPERABLE UNTIL SATISFACTORY REPAIRS CAN BE MADE. NEVER SACRIFICE THE SAFE OPERATION OF THE AUTOMATIC DOOR OR GATE FOR AN INCOMPLETE SOLUTION.WEB: WWW.BEASENSORS.COM