


- NOTES: 1 ) BEA RECOMMENDS USING THE LO-21  
 2 ) CONNECT LO-21 RED TO (A) AND BLACK TO (B) OF THE PLUG-IN PINS ON THE ACTIVATION RELAY COIL OF CONTROL BOX  
 3 ) THE SAFETY MODE SWITCH SHOULD BE IN SAFETY STD.  
 4 ) WHEN USING DC VOLTAGE, POLARITY MUST BE REPECTED ORANGE: (-) BROWN: (+)

IF AFTER TROUBLESHOOTING A PROBLEM, A SATISFACTORY SOLUTION CANNOT BE ACHIEVED, PLEASE CALL B.E.A., INC. FOR FURTHER ASSISTANCE DURING EASTERN STANDARD TIME AT 1-800-523-2462 FROM 8AM - 5PM. FOR AFTER-HOURS, CALL EAST COAST: 1-866-836-1863 OR 1-800-407-4545 / MID-WEST: 1-888-308-8843 / WEST COAST: 1-888-419-2564. DO NOT LEAVE ANY PROBLEM UNRESOLVED. IF YOU MUST WAIT FOR THE FOLLOWING WORKDAY TO CALL B.E.A., LEAVE THE DOOR INOPERABLE UNTIL SATISFACTORY REPAIRS CAN BE MADE. NEVER SACRIFICE THE SAFE OPERATION OF THE AUTOMATIC DOOR OR GATE FOR AN INCOMPLETE SOLUTION. WEB: WWW.BEASENSORS.COM

		100 ENTERPRISE DRIVE PITTSBURGH, PA 15275 PHONE: (412) 249-4100 FAX: (412) 249-4101 EMAIL: www.beasensors.com	
<b>TITLE: GYROTECH 300,400,500 WITH LO21, LO21S, BODYGUARD, DK12</b>			
SIZE: B	DRAWN BY: KJG SCALE: NONE	REV BY: WJR DATE: 09 FEB 2010	PART NO: 80.0087.04 SHEET 1 OF 1