



- NOTES: 1) INSERT SAFETY SIDE SUPERSCAN BLUE WIRE INTO PIN 6, BROWN WIRE INTO PIN 5, AND WHITE WIRE INTO PIN 1.
 2) THE MAGNETIC REED SWITCH SHALL OPEN AT APPROX. 65-70 DEGREES.
 3) THE BODYGUARD RELAY OUTPUT FUNCTION MUST BE CHANGED TO #2.
 4) IF USING A MAGNETIC REED SWITCH TO INHIBIT, SET CONTROL FUNCTION DIAL TO 6. IF NOT USING INHIBIT SWITCH, SET CONTROL FUNCTION DIAL TO 5.

IF AFTER TROUBLESHOOTING A PROBLEM, A SATISFACTORY SOLUTION CANNOT BE ACHIEVED, PLEASE CALL B.E.A., INC. FOR FURTHER ASSISTANCE DURING EASTERN STANDARD TIME AT 1-800-523-2462 FROM 8AM - 5PM. FOR AFTER-HOURS, CALL EAST COAST: 1-866-836-1863 OR 1-800-407-4545 / MID-WEST: 1-888-308-8843 / WEST COAST: 1-888-419-2564. DO NOT LEAVE ANY PROBLEM UNRESOLVED. IF YOU MUST WAIT FOR THE FOLLOWING WORKDAY TO CALL B.E.A., LEAVE THE DOOR INOPERABLE UNTIL SATISFACTORY REPAIRS CAN BE MADE. NEVER SACRIFICE THE SAFE OPERATION OF THE AUTOMATIC DOOR OR GATE FOR AN INCOMPLETE SOLUTION. WEB: WWW.BEASENSORS.COM

| | | | |
|---|----------------------|---|-------------------------------|
| | | 100 ENTERPRISE DRIVE PITTSBURGH, PA 15275 PHONE: (412) 249-4100 FAX: (412) 249-4101 EMAIL: www.beasensors.com | |
| TITLE: DOROMATIC ASTROSWSING WITH LO-21P PARALLAX II SYSTEM Q-DISCONNECT ON SAFTY SIDE | | | |
| SIZE: B | DRAWN BY: KJG | REV BY: KJG | PART NO: 80.0197.03 |
| SCALE: NONE | DATE: 28 NOV 2005 | SHEET 1 OF 1 | |