



- NOTES: 1) IF BODYGUARD HAS DOM INTERFACE CIRCUIT BOARD, IT MUST BE REMOVED.  
 2) THE MAGNETIC REED SWITCH SHALL OPEN AT APPROX. 65-70 DEGREES.  
 3) LO21 DIP SWITCHES: 1-5 LOCKOUT TIME WILL VARY, #6-8, (NOT USED).  
 4) IF USING A MAGNETIC REED SWITCH TO INHIBIT, SET CONTROL FUNCTION DIAL TO 6. IF NOT USING INHIBIT SWITCH, SET CONTROL FUNCTION DIAL TO 5.

IF AFTER TROUBLESHOOTING A PROBLEM, A SATISFACTORY SOLUTION CANNOT BE ACHIEVED, PLEASE CALL B.E.A., INC. FOR FURTHER ASSISTANCE DURING EASTERN STANDARD TIME AT 1-800-523-2462 FROM 8AM - 5PM. FOR AFTER-HOURS, CALL EAST COAST: 1-866-836-1863 OR 1-800-407-4545 / MID-WEST: 1-888-308-8843 / WEST COAST: 1-888-419-2564. DO NOT LEAVE ANY PROBLEM UNRESOLVED. IF YOU MUST WAIT FOR THE FOLLOWING WORKDAY TO CALL B.E.A., LEAVE THE DOOR INOPERABLE UNTIL SATISFACTORY REPAIRS CAN BE MADE. NEVER SACRIFICE THE SAFE OPERATION OF THE AUTOMATIC DOOR OR GATE FOR AN INCOMPLETE SOLUTION. WEB: WWW.BEASENSORS.COM

		100 ENTERPRISE DRIVE PITTSBURGH, PA 15275 PHONE: (412) 249-4100 FAX: (412) 249-4101 EMAIL: www.beasensors.com	
		<b>TITLE: DOROMATIC ASTRO-SWING WITH PARALLAX 2 SYSTEM (LO21) Q-DISC. ON APPROACH SIDE</b>	
SIZE: <b>B</b>	DRAWN BY: KJG	REV BY: TUC	PART NO: <b>80.0215.01</b>
SCALE: NONE	DATE: 13 OCT 2005	SHEET: 1 OF 1	