



- NOTES: 1) ASTRO-SWING CONTROL BOX MUST BE SET TO FUNCTION 5,6.
 2) IF BODYGUARD HAS DOM INTERFACE CIRCUIT BOARD, IT MUST BE REMOVED
 3) THE MAGNETIC REED SWITCH SHALL OPEN AT APPROX. 65-70 DEGREES TO INHIBIT THE SWING SIDE SUPERSCANS AND SHALL STAY OPEN UNTIL CLOSING CYCLE OCCURS AND THE SWITCH MAKES AT 65-70 DEGREES.
 4) IF USING A MAGNETIC REED SWITCH TO INHIBIT SWING SIDE SUPERSCANS, SET CONTROL FUNCTION DIAL TO 6. IF NOT USING INHIBIT SWITCH, SET CONTROL FUNCTION DIAL TO 5.

IF AFTER TROUBLESHOOTING A PROBLEM, A SATISFACTORY SOLUTION CANNOT BE ACHIEVED, PLEASE CALL B.E.A., INC. FOR FURTHER ASSISTANCE DURING EASTERN STANDARD TIME AT 1-800-523-2462 FROM 8AM - 5PM. FOR AFTER-HOURS, CALL EAST COAST: 1-866-836-1863 OR 1-800-407-4545 / MID-WEST: 1-888-308-8843 / WEST COAST: 1-888-419-2564. DO NOT LEAVE ANY PROBLEM UNRESOLVED. IF YOU MUST WAIT FOR THE FOLLOWING WORKDAY TO CALL B.E.A., LEAVE THE DOOR INOPERABLE UNTIL SATISFACTORY REPAIRS CAN BE MADE. NEVER SACRIFICE THE SAFE OPERATION OF THE AUTOMATIC DOOR OR GATE FOR AN INCOMPLETE SOLUTION. WEB: WWW.BEASENSORS.COM



		100 ENTERPRISE DRIVE PITTSBURGH, PA 15275 PHONE: (412) 249-4100 FAX: (412) 249-4101 EMAIL: www.beasensors.com	
TITLE: DOROMATIC ASTRO-SWING WITH PARALLAX 2 SYSTEM AND LO21S			
SIZE: B	DRAWN BY: K/JG	REV BY: K/JG	PART NO: 80.0080.04
	SCALE: NONE	DATE: 14AUG05	SHEET 1 OF 1