


**NOTES:**

- 1) MCLINX1'S, SUPERSCAN, BODYGUARD CAN SHARE POWER FROM 1 EXTERNAL TRANSFORMER PROVIDED IT HAS ENOUGH POWER TO POWER ALL SENSORS. A 24VAC 40VA IS RECOMMENDED. SEE MCLINX USER GUIDE FOR FURTHER INSTRUCTIONS.
- 2) POWER EL DEVICE VIA EXTERNAL POWER SOURCE. CONFIGURE MCLINX #1 RELAY "A" AS DRY OUTPUT AND WIRE IN SERIES AS SHOWN TO EL DEVICE.
- 3) DPS SHALL CLOSE WHEN DOOR CLOSES. CAN USE AUX. "B" CAM SWITCH.
- 4) FOR INCREASED BODYGUARD PATTERN DEPTH, WIRE 12VDC, (+) TO TERM. 7 & (-) TO TERM. 6.
- 5) ENSURE COMPLIANCE WITH ANSI 156.19 OR APPLICABLE STANDARD.

IF AFTER TROUBLESHOOTING A PROBLEM, A SATISFACTORY SOLUTION CANNOT BE ACHIEVED, PLEASE CALL B.E.A., INC. FOR FURTHER ASSISTANCE DURING EASTERN STANDARD TIME AT 1-800-523-2462 FROM 8AM - 5PM. FOR AFTER-HOURS, CALL EAST COAST: 1-866-836-1863 OR 1-800-407-4545 / MID-WEST: 1-888-308-8843 / WEST COAST: 1-888-419-2564. DO NOT LEAVE ANY PROBLEM UNRESOLVED. IF YOU MUST WAIT FOR THE FOLLOWING WORKDAY TO CALL B.E.A., LEAVE THE DOOR INOPERABLE UNTIL SATISFACTORY REPAIRS CAN BE MADE. NEVER SACRIFICE THE SAFE OPERATION OF THE AUTOMATIC DOOR OR GATE FOR AN INCOMPLETE SOLUTION. WEB: WWW.BEASENSORS.COM



100 ENTERPRISE DRIVE  
 PITTSBURGH, PA 15275  
 PHONE: (412) 249-4100  
 FAX: (412) 249-4101  
 EMAIL: www.beasensors.com

---

**TITLE: LOW ENERGY KNOWING ACT WASHROOM APPLICATION  
 2-MCLINX'1S, SUPERSCAN, BODYGUARD  
 BESAM 455 ETIK CONTROL**

SIZE:	DRAWN BY:	REV BY:	PART NO:
A	JED		80.0279.00
	SCALE:	DATE:	SHEET
	NONE	13 AUG, 2007	1 OF 1