



- NOTES: 1) SET B-SWITCH TO NORMALLY OPEN PIN AND VERIFY IT CLOSSES AT APPROX. 65-70 DEGREES.  
 2) INSTALL A JUMPER WIRE ON PINS 17, 18.  
 3) RH MOTOR SHOWN, REVERSE LO-21 RED AND BLACK WIRES FOR LH MOTOR.  
 4) HOLD ADJUSTMENT (HD) MAY NEED TO BE ADJUSTED TO APPROX. 12 VOLTS FOR PROPER OPERATION OF LOCKOUT.  
 5) INSERT SAFETY SIDE SUPERSCAN BLUE WIRE INTO PIN 6, BROWN WIRE INTO PIN 5, AND WHITE WIRE INTO PIN 1.

IF AFTER TROUBLESHOOTING A PROBLEM, A SATISFACTORY SOLUTION CANNOT BE ACHIEVED, PLEASE CALL B.E.A., INC. FOR FURTHER ASSISTANCE DURING EASTERN STANDARD TIME AT 1-800-523-2462 FROM 8AM - 5PM. FOR AFTER-HOURS, CALL EAST COAST: 1-866-836-1863 OR 1-800-407-4545 / MID-WEST: 1-888-308-8843 / WEST COAST: 1-888-419-2564. DO NOT LEAVE ANY PROBLEM UNRESOLVED. IF YOU MUST WAIT FOR THE FOLLOWING WORKDAY TO CALL B.E.A., LEAVE THE DOOR INOPERABLE UNTIL SATISFACTORY REPAIRS CAN BE MADE. NEVER SACRIFICE THE SAFE OPERATION OF THE AUTOMATIC DOOR OR GATE FOR AN INCOMPLETE SOLUTION.WEB: WWW.BEASENSORS.COM

		100 ENTERPRISE DRIVE PITTSBURGH, PA 15275 PHONE: (412) 249-4100 FAX: (412) 249-4101 EMAIL: www.beasensors.com	
<b>TITLE: BESAM 300/400 (ETIK2) WITH LO-21 PARALLAX II SYSTEM Q-DISCONNECT ON SAFETY SIDE</b>			
SIZE: B	DRAWN BY: KJG SCALE: NONE	REV BY: TUC DATE: 02 DEC 2005	PART NO: 80.0199.02 SHEET 1 OF 1